

## CT Scan Protocol

X-Ray Lab Technician:

The following details are required with completing the CT scan for the Nobel Clinician software. If you have any questions about the information listed, please contact Ryan Haupt at 714-529-9792 prior to completing the scan(s).

1. The CT device should be set to scan at a minimum of 10 seconds at .4 voxel slices for both the patient scan and appliance by itself scan.
2. First scan the patient with the clear acrylic appliance intraorally. Use the bite registration provided to stabilize the appliance.
3. In addition to the scan of the patient with the intraoral appliance we need another scan of the intraoral appliance by itself. *This scan should be done on a foam pad without the bite registration. Be sure to set the scan to start below the appliance to capture the complete detail.*
4. Provide the dicom data sets for both the patient and appliance (2 sets of dicom data) on a CDROM.

Please mail a copy of the CDROM to the doctor and Haupt Dental Lab

Haupt Dental Lab  
1220 E. Birch Street Suite 201  
Brea, CA 92821  
(714) 529-9792